



- | | | |
|---------------------------|----------------------------|--------------------------------|
| 1 Barrel | 21 Hammer Strut Pin | 41 Slide Stop Detent Plunger |
| 2 Barrel Bushing | 22 Magazine Release | 42 Sight Front |
| 3 Barrel Link | 23 Magazine Release Lock | 43 Sight Rear |
| 4 Barrel Link Pin | 24 Magazine Release Spring | 44 Thumb Safety |
| 5 Disconnecter | 25 Magazine | 45 Thumb Safety Detent Plunger |
| 6 Ejector | 26 Mainspring Cap | 46 Trigger |
| 7 Ejector Pin | 27 Mainspring Cap Pin | |
| 8 Extractor | 28 Mainspring Housing | |
| 9 Firing Pin | 29 Mainspring Pin | |
| 10 Firing Pin Spring | 30 Mainspring Retainer Pin | |
| 11 Firing Pin Stop | 31 Plunger Spring | |
| 12 Frame | 32 Plunger Tube | |
| 13 Grip Safety | 33 Recoil Spring | |
| 14 Grip Screw x 4 | 34 Recoil Spring Guide | |
| 15 Grip Screw Bushing x 4 | 35 Recoil Spring Plug | |
| 16 Grips x 2 | 36 Sear | |
| 17 Hammer | 37 Sear Pin | |
| 18 Hammer Pin | 38 Sear Spring | |
| 19 Hammer Strut | 39 Slide | |
| 20 Hammer Spring | 40 Slide Stop | |